


[www.disto.com/manuals](http://www.disto.com/manuals)

User Manual:



Laser class 2 in acc. with IEC 60825-1



SAP. No. 812 797b

## Change Units

Switch between the following units:



0.000m	0.00ft
0.0000m	0'00" 1/32

2 sec

0in 1/32

## Bluetooth®



1 x send  
2 sec deactivate/activate

# Quick Start

Leica DISTO™ E7100i




- 1
- 2
- 3
- 4

- 1 ON/DIST
- 2 Area
- 3 Bluetooth®
- 4 Clear/Off

- when it has to be **right**

**Leica**  
Geosystems

## Insert Batteries



## Operation



1x → ON


CLEAR  
OFF

2 sec → OFF



1x  →

## Attach/Remove Clip



## Area

